

BLUE DUCT®



Installation Instructions

CONTENTS

General.....	page 2	Boot Extension	page 5
Important	page 2	Linear Diffuser Assembly	page 5
Site Condition and Preparation.....	page 2	Plenum	page 6
Excavation	page 2	Connecting Plenum Adapter to a Linear	
Tools- Contractor Provided	page 3	Plenum or Diffuser Adapter	page 6
Tools- AQC Provided	page 3	Leak Testing	page 6
Sealant Application	page 3	Backfill	page 7
Connecting Flanged Duct.....	page 3	Backfill Detail (Less than 48" diameter)....	page 8
Connecting Non-flanged Duct	page 4	Backfill Detail (48" diameter)	page 8
Saddle	page 4	Warranty	page 9

CODE COMPLIANCE

This document, along with the *IAPMO REPORT 0261* and/or *ICC-ES LISTING PMG-1023* should be printed and readily available at the installation site. The BlueDuct® is a user-friendly system that will save installation time and labor. Installation videos, code documentation and this guide are provided on our website, www.aqcind.com. This document is to be used in conjunction with AQC Industries' installation training [offered via webinar on a regular basis](#). This document can be found on our website. Onsite installation training is offered based on availability. Consult your BlueDuct distributor or representative to arrange.

IMPORTANT

1. AQC Industries highly recommends all installing contractors complete AQC's provided training prior to installing The BlueDuct.
2. Strictly adhere to the following instructions.
3. The AQC sealant, clamp and Maxseal gasket material must be used as directed. The use of non-approved sealant or gasket will void the warranty.
4. For best results and ease of installation, store the clamps, gaskets and caulk at between 50° and 80°F.
5. For installing in high ambient temperatures above 90°F consult AQC Industries for special installation instructions.

SITE CONDITION AND PREPARATION

It is not prudent practice to install underground duct work where ground water is present. If ground water is present or anticipated, a permanent drain tile and pumping system is recommended before installation.

EXCAVATION

Coordination: Excavation work and trench elevations should be closely coordinated with the trained BlueDuct installer on site. It is recommended to share this information with the on-site general contractor and excavation crew.

Soil Type: If non-porous soil (i.e. clay, shale, solid rock) is present a sump pumping or drainage system is recommended to ensure the water is re-directed.

Width: For non-flanged duct, the trench width should be wide enough to straddle the duct. For flanged duct, the trench width should be 1 1/2 times the duct diameter or wide enough to allow the installer to access the bolts. Where multiple ducts are installed side by side, the minimum separation must allow for reasonable access for proper installation.

Bedding: After the excavation has been made, special bedding is not required for The BlueDuct. The BlueDuct can rest on the foam trench blocks provided by AQC.

TOOLS- Contractor Provided

- | | |
|---|--|
| 1. Circular saw, reciprocating saw, or jig saw | 9. Caulk gun- manual |
| 2. Adjustable clutch drill with 1/4" and 5/16" hex driver and 7/16"-deep socket | 10. Caulk gun- battery operated |
| 3. Drills (impact and clutch) | 11. Safety glasses |
| 4. Torque Wrench | 12. Gloves (recommended for sealant application) |
| 5. 7/16" wrench (to install flanged duct) | 13. Shop rags |
| 6. Crescent wrench (to install 48" duct only) | 14. Black permanent marker |
| 7. Utility Knife | 15. 90° drill attachment & 1/4 drill bit |
| 8. Hammer | 16. Rasp or Scraper |

TOOLS- AQC Provided* (Specifically designed to install flanged BlueDuct)

1. Circular saw with cutting jig
2. Alignment straps (20"-24", 30"-36", 48")
3. Alignment pins (4/box)

****Contact your BlueDuct distributor or representative to obtain tools***

SEALANT APPLICATION

1. Apply 1/2" bead of sealant.
2. Run finger around the perimeter to ensure a proper seal.
3. Sealant should be visibly seeping out. Apply additional sealant as needed.
4. Cover all screw heads and bolts with sealant using hand held caulk gun.

CONNECTING FLANGED DUCT

For best results in connecting and sealing flanged duct, cut in the middle of a rib, keeping both sides even throughout the entire circumference of the duct. (The supplied circular saw with cutting jig will assist this operation)

1. Put two beads of The BlueDuct sealant on each of the connecting flanged pieces.
2. Use alignment straps and alignment pins to help keep the duct in place. Alignment straps are available for 20" to 48"-diameter ducts. Contact your representative to obtain The BlueDuct tools.
3. Once connected, apply The BlueDuct sealant to the flange, ensuring that there is no area void of sealant.
4. Apply a bead of The BlueDuct sealant on the interior of the connection in addition to the exterior of the flange.
5. Run finger around the perimeter to ensure a proper seal.
6. Use an adjustable clutch-drill to tighten bolts with the torque set between 25 and 30 in. lbs. of torque or enough to flatten the washers. An impact-drill is not acceptable, as it will not allow for uniform tightening of the bolts.
7. After bolts are tightened, caulk over both sides of the bolts with The BlueDuct sealant.
8. When the duct needs to be cut between the flanges, use a clamp and gasket to connect the ducts.
9. All flanged 90°, 45° and custom angles are field drilled to allow for as much field flexibility when installing BlueDuct. A factory flange should be used as a guide and every hole must be drilled and bolted.



BDIM093023




CONNECTING NON-FLANGED DUCT

The BlueDuct round duct can be easily cut with a circular saw. Trim all edges as necessary. To ensure a proper connection, all cuts made should not exceed 4°.

Required items:

- Clamp with factory installed screws
- Maxseal gasket material
- Drill
- 8" and 10" clamps include three 3" threaded stainless screws
- 12", 14", 16" and 18" clamps include four 3" threaded stainless-steel screws for each half clamp, with a guide insert



1. Place two sections of duct end to end with the clamp on one of the ducts (while keeping the duct sections tight).
2. Slightly stretch the gasket around the duct and apply pressure to ensure 3/4" overlap.
3. Place the clamp around the gasket, lining up the clamp with the gasket.
4. Tighten the clamp screws with the adjustable clutch drill.
5. The clamp should be tightened until it's snug around the connection.

Note: Moving of pre-assembled non-flanged duct is not recommended. All non-flanged connections should be made in the trench.

Caution:

1. **The two ends of the clamps do not have to meet each other to be airtight.**
2. Tightening the screws too fast may cause galling.
3. Over-tightening the screws may cause damage to the clamp.



Peel off gasket backing



Tack gasket halfway around duct



Tack gasket down and apply pressure



Slide clamp over gasket and tighten screws

SADDLE


1. Center the saddle on top of the round duct at the desired air supply register location. Trace around the saddle with a black permanent marker.
2. Use the outline created as a template. Draw another line 1-1/2" inside the first outline. Cut on the inner line and remove any loose material from inside the round duct.
3. Apply a 1/2" bead of The BlueDuct sealant on the underside of the saddle and the straight duct surfaces.
4. Place the saddle on the round duct plumb and level.
5. Place the 1.25" saddle screws in the pre-marked locations on the saddle. All of the screws must be used to create a good seal. Screws must be installed such that they do not break the saddle surface.
6. Caulk around the saddle with The BlueDuct sealant after the screws have been installed and cover screw heads with sealant.
7. Once the concrete has been poured, cut off the protruding caps and install the floor register.



Draw outside line



Cut along inside line



Cut square edges



Remove Cut Panel



Continuous 1/2"
sealant bead.



Continuous 1/2"
sealant bead.



Secure both ends and drill screws into pre-marked locations and cover screw heads with sealant.

BOOT EXTENSION

Allows the BlueDuct underground system to extend the register locations if elevations vary.

1. Cut off the top 3/4" of the 90° boot diffuser.
2. Apply the AQC sealant around the outer surface.
3. Apply a bead of sealant on the inner sleeve of the boot extension and slide the boot over the top of the diffuser.
4. Secure both sections with screws, 1.25" every 6".



LINEAR DIFFUSER ASSEMBLY

This process is similar to cutting in and attaching a BlueDuct saddle.

1. Set the diffuser box on a flat surface with the cooling hole facing up.
2. Set the linear diffuser adaptor, flared end down, on the diffuser box.
3. With a marker, trace the outside perimeter of the linear diffuser adaptor on the diffuser box.
4. Draw another line 1 1/2" inside the first outline.
5. Cut out along the inner template line. Remove any tailings or loose material along or inside the diffuser box.
6. Caulk and join per "Sealant Application" section on page 3.
7. Mount plenum adaptor to the desired location on the outer face of the LDA. Refer to "Connecting Plenum Adapter" instructions on page 6.




Note: In instances where the diffuser box is wider than the linear diffuser adaptor, the diffuser box does not need to be centered on the linear diffuser adaptor. This will allow the installer some flexibility towards achieving the desired placement of the diffuser box.

PLENUM

The BlueDuct plenum is a complete unit designed to transition the underground duct to the above-ground duct or equipment. The plenum should extend 2"-8" inches above the slab.

1. Place the plenum in the desired location and insert the plenum.
2. Mark the take-off location and cut the hole at the desired elevation.
3. Each diffuser boot is a legal clean-out. Mark the furnace opening, above-ground duct or other equipment and cut the plenum or use a template for a quick and easy guide for cutting the plenum.



PLENUM

1. Hold the plenum adapter up to the plenum at the desired location and trace around the inside and outside with a black permanent marker.
2. Use a jigsaw or reciprocating saw to cut out the smaller circle to fit the plenum adapter.
3. Apply a 1/2" bead of sealant to both surfaces.
4. Secure with 2.25" plenum adapter screws (secure with 1.25" saddle screws for 8" plenum adapters) and caulk around the plenum with sealant (refer to the "Sealant Application" section on pg. 3).



All screws must be used to ensure the plenum adapter has been sealed. The images below illustrate how to create and use a template marked area.

LEAK TESTING

To best ensure a quality installation, the dynamic ("duct blaster") equipment and test method per SMACNA guideline is recommended. Consult your engineer, general contractor or owner for acceptable leak test standards.

1. Allow 24 hours for AQC sealant to cure before performing the leak test. In high ambient temperature conditions, additional curing time may be required.
2. Wait a minimum of 24 hours after the last caulked connection has been made to perform a leak test.

3. Test the duct up to 2" w.c. for five minutes.
4. If testing at a higher pressure and/or longer duration is required, consult AQC.

Note: Additional cure time may be required.

BACKFILL

Pea gravel, dry silica sand, crush rock 3/4" or less (if tumbled) or engineered fill is required. Generally pea gravel does not need further compaction. However, if additional compaction is required it should never be done directly on top of the BlueDuct, but rather off to the sides. Additionally, backfill should never be dumped directly on top of the BlueDuct, but should be applied by raking in from the sides. Consult your Project Structural Engineer for these needs.

1. Spread the backfill material evenly around the duct, in no more than 1ft. lift increments, and ensure there are no gaps. Cement is not required to fill in around the duct since the self-compacting fill holds the duct in place.
2. If compaction is going to take place, use extreme care not to damage the BlueDuct. AQC does not recommend the use of heavy mechanical equipment. If a gentle compaction technique is used, a manually operated walk behind 2' by 2' plate tamper is recommended. The use of "jumping jacks", "rammers" and machinery equipment are prohibited.


If heavy rain or increasing water table is likely to occur prior to backfilling, it is recommended that the duct be anchored. **Note:** Runoff and proper drainage is critical to maintain in open trenches and pre-slab conditions to prevent buoyancy. Contact AQC Industries for anchoring recommendations.

Important: Allow a minimum of 24 hours for the sealant to sufficiently cure before backfilling. It is strongly encouraged to backfill 24 to 48 hours after installation to protect the open trench from filling with water during a heavy rain. If the duct is fully assembled, sealed and not yet backfilled, protect the duct from extreme heat and direct sunlight to prevent the air trapped inside the duct from reaching an elevated temperature. In temps above 90°, consider backfilling early morning or late evening in cooler temps.


Equipment Only Crossover: For cross over traffic with equipment, a slurry cap should be placed over the duct and must span the trench. Consult with a project structural engineer when backfilling or grading, care should be taken to not push heavy loads directly on the duct. Running heavy equipment over the duct should be avoided. The BlueDuct can be crushed under careless abuse.

Use extreme caution once installed and backfilled. The BlueDuct is never intended to be driven over before concrete is poured.

BACKFILL DETAIL (LESS THAN 48")



BACKFILL DETAIL (48")



WARRANTY

AQC Industries Limited Warranty in General

AQC Industries (AQC) warrants The BlueDuct Products sold either directly or through its resellers (representatives and distributors) in accordance with the limited warranty set forth in this document (the Limited Warranty). Except as expressly provided in the Limited Warranty, AQC makes no representation or warranty of any kind, express or implied, with respect to The BlueDuct Product, whether as to merchantability, fitness for a particular purpose, warranties arising from course of dealing or usage or trade or any other matter.

AQC does not install The BlueDuct Products and has no responsibility or obligation with respect to installation. AQC DISCLAIMS ALL WARRANTIES RELATED TO INSTALLATION OF THE BlueDuct PRODUCTS. AQC offers webinar based BlueDuct Installation Training Certification to installing contractors at no charge, and recommends this training prior to installing The BlueDuct Product.

AQC Industries Limited Warranty

AQC Industries (AQC) warrants that in normal and contemplated use and service, The BlueDuct Products shall be free from defects in manufacturing materials and workmanship for a period of ten (10) years from the date of manufacture set forth on each of The BlueDuct Products (the Limited Warranty). The Limited Warranty shall only be applicable if AQC is given prompt written notice specifying the nature of the warranty claim within the applicable warranty period.

Upon confirmation by AQC that a BlueDuct Product proves to be defective in manufacturing, materials or workmanship, the exclusive remedy shall be for AQC to, at its option, repair or replace the defective BlueDuct Product or issue a credit or refund. The Limited Warranty does not extend to any BlueDuct product subjected to misuse, accident, or alteration. This Limited Warranty does not extend to improper installation.

This Limited Warranty does not cover any loss caused by accidents or careless handling of a BlueDuct Product. This Limited Warranty does not apply to any BlueDuct Product which has been damaged in transit, abused, altered, modified, used in a manner not originally intended, or used. This Limited Warranty does not cover any BlueDuct Product that has been installed in a manner not consistent with The BlueDuct Product instructions.

The Limited Warranty set forth above is the only warranty AQC makes for The BlueDuct Products and is in lieu of all warranties express, implied or statutory, including, without limitation, warranties of merchantability, fitness for a particular purpose and infringement, and warranties arising from course of dealing, usage of trade or otherwise. THE REMEDIES SET FORTH IN THIS LIMITED WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON CLAIMING FOR BREACH OF WARRANTY OR FOR ANY DAMAGES OF ANY KIND OR NATURE. AQC SHALL NOT HAVE ANY OTHER LIABILITY OF ANY DESCRIPTION, WHETHER ARISING OUT OF WARRANTY (INCLUDING ANY IMPLIED WARRANTIES) OR ANY OTHER CONTRACT, NEGLIGENCE, TORT OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO, COST FOR REMOVAL OF DEFECTIVE PRODUCT, COST FOR INSTALLATION OF ANY REPLACEMENT PRODUCT, COMMERCIAL LOSS FROM ANY CAUSE, BUSINESS INTERRUPTION OF ANY NATURE, LOSS OF PROFITS OR ANY OTHER CONSEQUENTIAL LOSS OR DAMAGE, EVEN IF AQC SHALL HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE.

In the event any implied warranties (including, but not limited to the implied warranties of merchantability and fitness for a particular purpose) are found to exist, such warranties are limited (i) in duration to the period of the limited warranties set forth in this Limited Warranty, and (ii) in amount to the total amount paid to AQC for the product in question.